

## Installation Information

Radio interface for 26-pin Accessory Port Connector


Normally open switch connection for emergency signal

Has Ignition Sense wire


External Speaker connection.

If an external speaker is not required, insulate external speaker wires with heat-shrink tubing.

## RC-xxMTM Cable



### Back View MTM5x00



### Front View 26-pin connector

